OVEN PARTS

For Model: SB160PEDQ1,SB160PEDB1
(Designer White) (Black)

24" BUILT−IN−OVEN
GAS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Model: SB160PEDQ1,SB160PEDB1
(Designer White) (Black)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	816860	Insulation, Top
2	816906	Retainer−Oven Top
3	816885	Shield, Switch Rod
4	816888	Shield, Top And Sides
5	816852	Box, Flue
6	816861	Insulation
7	816909	Shield, Oven Top
	313823	Screw, #8x22x5/16 (10)
8	816867	Insulation, Back
9	816864	Insulation, Bottom
10	816866	Insulation, Top & Sides
11	4372514	Bracket, Safety Valve
12	816923	Box, Burner
	308685	Screw, #10x24x1/2 (11)
13	4372163	Bottom, Oven
15	4372517	Spring, Door (2)
16	4372518	Hinge, Door (2)
17	4372516	Hinge Assembly
19	4372162	Frame, Front
21	4372483	Shield, Flue Bottom
22	816890	Shield, Flue Top
	313638	Screw, #8x20x1/2 (12)
23	4372501	Spring, Support
24	816893	Support, Oven Front (2)
25	4372499	Clip, Oven Mtg. Adjustment (2)
	816325	Screw, #6x32x1/2 (6)
26	816894	Switch, Thermo
	241428	Screw, #10x24x1/2 (2)
31	816291	Retainer, Lens
32	4372021	Lens, Oven Lamp
33	4371303	Lamp, Oven
34	4372491	Socket, Lamp
36	816877	Sensor
	241428	Screw, #10x24x1/2 (2)
38		Trim, Inner
	816899	Right Side
	816900	Left Side
39	816883	Shield, Insulation (Base)
40	4372165	Liner, Oven
43	816895	Switch, Oven Light
	310211	Screw, #4x40x1 (2)
45	816905	Wrapper, Back And Sides
46	816886	Shield, Body Sides
49		Trim, Outer Side
	816915	White
	816848	Black
50	816887	Bottom, Oven
51	4372521	Rack, Oven
52	816382	Pan, Broiler
53	4371169	Grid, Broiler Pan
56	816813	Blower
57	4372522	Bracket, Switch Mounting
58	4372523	Bracket, Thermostat
	241428	Screw, #10x24x1/2 (2)
60	816608	Bumper (2)
61	816846	Duct, Blower Motor
62	816851	Adaptor, Fluebox
63	816388	Channel, Hinge (2)
64		Insulation, Bottom
	816862	Sides (2)
	816863	Front
65	816879	Rod, Switch
66	816880	Shield, Lower Oven
67	4372524	Shield, Housing
	241428	Screw, #10x24x1/2 (4)
68		Trim, Base
	4372503	Black
	816921	White
	816410	Screw (2)
69	4372495	Shield, Oven Bottom

FOLLOWING PARTS NOT ILLUSTRATED

816387	Spacer, Oven (2)
816865	Insulation, Bottom
816869	Support, Oven Rear

CONTROL PANEL PARTS

For Model: SB160PEDQ1,SB160PEDB1
(Designer White) (Black)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Switch, Oven Light
	4372550	White
	4372465	Black
2		Bezel, Switch
	4372551	White
	4372472	Black
3	4372166	Plate, Instrument Mtg.
	241428	Screw, #10x24x1/2 (4)
6	816812	Fastener, Wire
8	816857	Base, Latch Motor
9	816874	Clock/Oven Control
	786753	Nut, #6x32 (4)
	816302	Screw, #6x32x1/2

Illus. No.	Part No.	DESCRIPTION
13		End Cap
		White
	816912	Right Side
	816913	Left Side
		Black
	816829	Right Side
	816830	Left Side
16		Deflector, Heat
	816917	White
	816850	Black
	487010	Screw, #6x18x1/4 (3)
18		Trim, Center Vent
	816914	White
	816847	Black
	816325	Screw, #6x32x1/2 (4)
21	816872	Nut, 10 x 24
24	816871	Motor, Lock
	241428	Screw, #10x24x1/2 (3)
25	4371168	Stud, Latch
27	4371167	Lever, Lock
29		Knob, Clock
	4372552	White
	4372528	Black

Illus. No.	Part No.	DESCRIPTION
30		Trim, Top
	4372553	White
	4372529	Black
	816325	Screw, #6x32x1/2 (6)
34		Panel, Control
	4372554	White
	4372531	Black
39	4371174	Housing, Latch
40		Button, Control(9)
	4372555	White
	4372532	Black
41	4372533	Rod, Latch Support
42		Trim, Control Panel (2)
	4372556	White
	816898	Black
43	816907	Shield, Controls
	313823	Screw, #8x22x5/16 (8)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER PARTS

For Model: SB160PEDQ1,SB160PEDB1
(Designer White) (Black)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	816870	Mixer, Broiler
3		Igniter
	4372534	Bake Burner
	4372535	Broiler Burner
	877919	Screw, #8x32x3/8 (2)
6	4372537	Fitting, Elbow
	241428	Screw, #10x24x1/2 (2)
8	816820	Elbow, Mixer
10	816902	Tubing, Mixer
11	816903	Tubing, Safety Valve
12	816904	Valve, Safety
	241428	Screw, #10x24x1/2 (2)
15	816873	Nut, Wing
18	816926	Regulator
19	4372475	Valve, Shut Off
20	4372502	Cord, Power
28	816825	Burner, Bake
32	4372538	Baffle, Bake
35	4372539	Burner, Broiler
38	4372164	Shield, Broil Burner
	816270	Screw, #10x24x5/8
40	816827	Baffle, Broiler
	241428	Screw, #10x24x1/2 (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Model: SB160PEDQ1,SB160PEDB1
(Designer White) (Black)



DOOR AND DRAWER PARTS

For Model: SB160PEDQ1,SB160PEDB1
(Designer White) (Black)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4372541	Baffle, Door
2	4372542	Seal, Window
3	4372543	Insulation, Door
4	816838	Seal−Oven Door
6	4372544	Liner, Door
	816270	Screw, #10x24x5/8 (4)
10		Glass, Outer Door
	4372557	White
	4372478	Black
12	816840	Frame, Door
	3149333	Screw, #8x18x1/2 (3)
13		Handle, Door
	4372558	White
	4372477	Black
	816359	Screw, #10x24x21/4 (2)
14		Spacer
	4372282	White
	816440	Black
16	816377	Glass, Inner
20	877507	Strike
23	816513	Glass, Inner Door
25	816505	Spacer, Button
	816505	Button, Plug
27	816720	Spacer, Handle
28	816509	Collar, Glass
	241428	Screw, #10x24x1/2 (4)
29	816508	Panel, Airwash
30	816841	Drawer, Storage
	816755	Screw, #8x18x3/8 (4)
31	4372547	Roller
32	816844	Panel, Inner Door
33		Panel, Glass
	4372559	White
	816842	Black
34		Handle, Drawer
	816982	White
	816834	Black
	816270	Screw, #10x24x5/8 (2)
35		Spacer, Handle
	4372282	White
	816440	Black
36		Track, Drawer
	816896	Right Side
	816897	Left Side
	308685	Screw, #10x24x1/4 (4)
	816872	Nut, #10 x 24 (4)

LITERATURE PARTS

LIT4371010	Installation Instructions
LIT4363412	Guide, Use & Care
LIT4372536	Wiring Diagram